


Spider Feet Sign Holder Small & Large

210380, 210381

Product Parts

- 1 - Foot*
- 2 - Screw
(Not Included - x1 per holder)
- 3 - Wing Nut
(Not Included - x1 per holder)

*Sold Individually - Pairs recommended for most applications




Display Set-Up

Step 1

Remove the Foot (1) from the box and place on a clean, flat surface along with the Screw (2 - not included) and Wing Nut (3 - not included).

Step 3


Place the Graphic back in the Graphic Slit and line-up the drilled holes of the Graphic with the Screw Fixture Holes.



Insert the Screw (2 - not included) through the Screw Fixture Holes and Graphic Hole. Tighten in place with a Wing Nut (3 - not included).

Step 2

Slip the Graphic into the Graphic Slit. With the Feet in their desired positions, mark the Screw Fixture Holes on the Graphic, and pre-drill the holes in the Graphic.



Step 4

Place assembled display in your desired location and set-up is complete.



Storage

Place Foot in box and store in a cool, dry location.

Care

To clean, wipe with damp cloth.

Warranty Information: All products are designed to provide the user with a cost-effective and durable product. Standard warranty is a 'one year parts and labor' warranty which warrants product against defects in material and workmanship. It does not cover damage due to accidents, abuse, or normal wear and tear. Products found to be defective will be replaced or repaired at factory's discretion.