
Spider Feet Sign Holder Jumbo




Display Set-Up

Step 1

Remove both sides of the Foot (1) from the box and place on a clean, flat surface along with the Screw (2 not included) and Wing Nut (3 - not included).

Place your graphic upright, between both Foot (1) sides.



Step 2

With the Foot (1) sides in the desired positions, mark the Screw Fixture Holes on the Graphic. Remove the Graphic and pre-drill the hole marks.



Step 3

Place the Graphic back between the Foot (1) sides and line-up the drilled holes of the Graphic with the Screw Fixture Holes.

Insert the Screw (2 - not included) through the Screw Fixture Holes and Graphic Hole. Tighten in place with a Wing Nut (3 - not included).

Step 4 Place assembled display in your desired location and set-up is complete.



Storage & Care

Place Foot in box and store in a cool, dry location. To clean, wipe with damp cloth.

Warranty Information: All products are designed to provide the user with a cost-effective and durable product. Standard warranty is a 'one year parts and labor' warranty which warrants product against defects in material and workmanship. It does not cover damage due to accidents, abuse, or normal wear and tear. Products found to be defective will be replaced or repaired at factory's discretion.