



Floor Decor

Product Parts


1 - Graphic



Display Set-Up


Step 1

Unroll the Graphic (1) from the box.



Step 2



OPTIONAL:
If necessary, on some surfaces the Graphic (1) may shift slightly. To avoid this it is recommended to use two-sided carpet tape on the edges of the back side of the Graphic (1) (available at any local hardware store).



Many surfaces will not need the carpet tape.

Step 3

If using carpet tape, remove the backer from the tape and adhere the Graphic (1) to your desired location.



Storage & Care

DO NOT FOLD YOUR FLOOR GRAPHIC. Roll Graphic face out to avoid creases.

Store in a cool, dry place. Scuff marks or dirt can be removed with a mild detergent and a clean, damp cloth.