

Product Specifications

Viewable Graphic Size: 117"w x 79" h
Graphic Template Available

Product Parts

1 - Event Tent Full Wall



Set Up Instructions

Step 1

Before you begin have tent legs in their lowest position.

On outside of Tent fasten top corner of the Event Tent Full Wall loop to hook on tent frame (if canopy is in position it will need to be removed at corners)



Step 2

Repeat the process on the opposite tent corner. Fasten the sides and top of the Event Tent Full Wall to the tent frame by looping the straps around the frame.



Step 3

Place canopy into position. Secure hook on underside of canopy corner over loop on Event Tent Full Wall. *If you are attaching another Event Tent Full Wall skip this step and proceed to Step 4.*

Step 4

Attach another Event Tent Full Wall by zippering together at the corner. Secure to tent frame by repeating steps 1 thru 3.

Once all the Event Tent Full Walls and canopy are in place extent tent legs to their desired position.

