Indus
10' X 20' KIT



Thank you for your purchase of Orbital Expo Truss Extreme. These instructions show how to erect the kit you purchased. The color coded section will help identify the location of each part.

6-WAY JUNCTION BOX (OR-J-2)	14
45 CURVED TRUSS SECTION (OR-45-CV-2)	4
LEFT (OR-TBL2-L-S/WD*) / RIGHT (OR-TBL2-R-S/WD*) ADJUSTABLE SCALLOP TABLE TOP	0 / 0
(OR-IS-24-S/WD*) 24"	0
(OR-IS-36-S/WD*) 36"	0
(OR-IS-46-S/WD*) 46" INTERNAL SHELVES	6
24" LONG TRUSS SECTION (OR-24-2)	0
90 CURVED TRUSS SECTION (OR-90-CV-2)	0
50 WATT CHROME SPOTLIGHT (LUM-1-C)	6
ORBITAL FREIGHT CASE (OCF)	2
36" LONG TRUSS SECTION (OR-36-2)	7
UNIVERSAL CONNECTOR (OR-UNI-CLP-1)	0
TRUSS TO JUNCTION CONNECTION KIT (OR-QL-T2J)	38
ORBITAL FREIGHT CASE (OCT)	0
46" LONG TRUSS SECTION (OR-46-2)	15
ADJUSTABLE TABLE TOP (OR-TBL-S/WD*)	0
TRUSS TO TRUSS CONNECTION KIT (OR-QL-T2T)	7

Each Orbital Expo Truss Extreme kit has been carefully designed and developed to be stable and safe. Consult with your dealer for load bearing specifications. The manufacturers of Orbital Expo Truss Extreme will not be held responsible or accountable for damage or injury caused by exceeding guidelines or though wrongful/incorrect use of the system.

(* S = Brushed Silver Finish WD = American Natural Wood Finish)

Indus
10' X 20' KIT



Color Coded Components





ORBITAL EXPRESS expo truss

Indus
10' X 20' KIT



Color Coded Components